

PRELASTI BONDED TO SIPs

1. 1.2mm Prelasti EPDM Membrane (black)

2. P150 slow curing adhesive

3. Dependant on the panel fixing type, a further layer of insulation may be required here

4. SIP

5. Vapour control in this build up is the responsibility of the manufacturers / installers of the panel

6. Falls are project specific

